



STEP 1



STEP 2



STEP 3









STEP 4

The user now selects the profile they want to use and they click Next.












STEP 5

They can customize their profile. When done, they click Save.

Thermostats: selection of the adjustments for the preheat period and the peak period


Load controllers: selection if the device is participating or non-participating.







Unsubscribe info





DR event

